영상처리

CHAPETR 02 영상 및 비디오 입출력

2019. 3 한밭대학교 정보통신공학과 이충호

- ► Input/Output, Displaying, Saving of image files
 - ▶ [] options, → return values of functions
- ► Table 2. Input output and display functions for images

Function	
cv2.imread(filename[,flags])->retval	Read an image
cv2.imwrite(filename,img[,params])->retval	Write an image
cv2.namedWindow(winname, [,flags])	Create a window
cv2.imshow(winname,mat)	Display an image
cv2.waitkey([delay])->retval	Wait a keyboard input
cv2.destroyWindow (winname)	Destroy an window
cv2.destroyAllWindows()	Destroy all windows

► Try 0201.py~ 0206.py.

0201.py :영상 파일 읽기 및 파일 표시

512x512 size, 3 channels, BGR(Blue Green Red)

waitKey(): delay = 0, wait a keyboard input infinitely.


0202.py: 영상 파일 저장

compression rate 9, compressing range [0, 9], takes longer time for high compression, default value is 3

[cv2.IMWRITE_JPEG_QUALITY,90] 90% quality, quality range [0,100], default 95

0202.pycv2,cvtColor(imgBGR, cv2.COLOR_BGR2RGB) # cvt means convert

import cv2 from matplotlib import pyplot as plt imageFile = './data/lena.jpg' imgBGR = cv2.imread(imageFile) plt.axis('off') plt.imshow(imgBGR) plt.show()




▶ 0203.py 컬러 영상 표시 cv2,cvtColor(imgBGR, cv2.COLOR_BGR2RGB) # cvt means convert

import cv2
from matplotlib import pyplot as plt


imageFile = './data/lena.jpg'
imgBGR = cv2.imread(imageFile)
plt.axis('off')
#plt.imshow(imgBGR)
#plt.show()

imgRGB = cv2.cvtColor(imgBGR,cv2.COLOR_BGR2RGB)
plt.imshow(imgRGB)
plt.show()



▶ 0204.py 그레이스케일 영상표시 plt.imshow(imgGray, cmap='gray, interpolation='biscubic')

biscubic: 인접한 16개의 화소값과 거리에 따른 가중치로 보간



- ▶ 0205.py 여백조정 및 영상저장
- plt.figure(figsize=(6,6))

plt.figure(figsize=(6,6)) # figure size is 6 inches x 6 inches plt.subplots_adjust(left=0, right=1, bottom=0, top=1)#출력범위 left<right bottom < top




그림 2.4 Matplotlib 여백제거

▶ 0206.py 서브플롯에 영상표시

Read four images

Convert images BRG to RGB

fig, ax = plt.subplots(2, 2, figsize=(10,10), sharey=True) # 2x2 subplot, 10x10 size

ax[0][0] # top left

ax[0][1] # top right

ax[1][0] # bottom left

ax[1][1] # bottom right




그림 2.5 Matplotlib을 이용한 다중 영상 표시

- Anlog to digital
- ▶ Frame
- ► A video is a sequence of frames
- ▶ VideoCapute(), while, Videocapture.read(), esc key 표2.2 비디오프레임 캡처와 화면 표시 함수

Function	Explanation
cv2.Videocapture(), cv2.Videocaputure(filename), cv2.VideoCaputure(device) -> < VideoCaputrue object>	Capture a video and create an object
cv2.VideoCaputure.read([image])->retval, image	Read a frame
cv2.VideoCaputure.grap()->retval	Grab a frame
cv2.VideoCaputure.retrieve([image[,channel]])->retval,image	Retrieve a frame
cv2.VideoCaputure.release()	Release a frame
cv2.VideoCaputure.get(propid) -> retval	Get features of a video
cv2.VideoCaputure.set(propid, value)->retval	Set features of a video

02. 비디오 프레임 캡처

표2.3 Property ID 주요상수

Property_id	explanation
cv2.CAP_PROP_POS_MSEC	Milliseconds position
cv2.CAP_PROP_POS_FRAMES	Frame number to capture
cv2.CAP_PROP_FRAME_WIDTH	Frame width
cv2.CAP_PROP_FRAME_HEIGHT	Frame height
cv2.CAP_PROP_FPS	Frame per second
cv2.CAP_PROP_FOURCC	Four characters of Codec
cv2.CAP_PROP_FRAME_COUNT	Total number of frames of a video
cv2.CAP_PROP_CONVERT_RGB	Convert to RGB
cv2.CAP_PROP_FORMAT	Format of video
cv2.CAP_PROP_BRIGHTNESS	Brightness of camera
cv2.CAP_PROP_CONTRAST	Contrast of camera
cv2.CAP_PROP_SATURATION	Saturation of camera
cv2.CAP_PROP_HUE	Hue of camera
cv2.CAP_PROP_GAIN	Gain of camera
cv2.CAP_PROP_EXPOSURE	Exposure of camera

```
#0207.py
Import cv2
Cap = cv2.VideoCapture(0) # 0번 카메라
#cap = cv2.VideoCapture('./data/vtest.avi') # 저장된 video 이용 시
Cap.set(cv2.CAP_PROP_FRAME_WIDTH, 320) #카메라 이용 시
Cap.set(cv2.CAP_PROP_FRAME_HEIGHT, 240) #카메라 이용 시
Frame_size = (int(cap.get(cv2.CAP_PROP_FRAME_WIDTH)),
       int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT)))
Print('frame_size =', frame_size)
While True:
  retval, frame = cap.read() # 프레임 캡처
  if not retval:
    break
  cv2.imshow('frame',frame)
  key = cv2.waitKey(25) # esc key 누르면
  if key == 27: # Esc
    break
if cap.isOpened():
  cap.release()
cv2.destroyAllWindows()
```

```
# 0208.py
import cv2
#cap = cv2. VideoCapture('http://192.168.0.21:4747/mjpegfeed') # droid cam
cap = cv2.VideoCapture('http://192.168.0.21:4747/mjpegfeed?640x480')
cap = cv2.VideoCapture('http://192.168.0.21:4747/video') # IP Webcam
frame_size = (int(cap.get(cv2.CAP_PROP_FRAME_WIDTH)),
       int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT)))
print('frame_size =', frame_size)
while True:
  retval, frame = cap.read() # 프레임 캡처
  if not retval:
    break
  cv2.imshow('frame',frame)
  key = cv2.waitKey(25)
  if key == 27: # Esc
    break
if cap.isOpened():
  cap.release()
cv2.destroyAllWindows()
```

```
# 0209.py
pip install youtube dl
pip install pafy
import cv2, pafy
url = 'https://www.youtube.com/watch?v=u_Q7Dkl7Alk'
video = pafy.new(url)
print('title = ', video.title)
print('video.rating = ', video.rating)
print('video.duration = ', video.duration)
best = video.getbest(preftype='webm')
                                          # 'mp4','3qp'
print('best.resolution', best.resolution)
cap=cv2.VideoCapture(best.url)
while(True):
gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
    edges = cv2.Canny(gray,100,200) #Canny edge detection
    cv2.imshow('edges',edges)
cv2.destroyAllWindows()
```

03. 비디오 파일 녹화

```
# 0210.py
import cv2
cap = cv2.VideoCapture(0) # 0번 카메라
frame_size = (int(cap.get(cv2.CAP_PROP_FRAME_WIDTH)),
       int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT)))
print('frame size =', frame size)
#fourcc = cv2.VideoWriter_fourcc(*'DIVX') # ('D', 'I', 'V', 'X')
fourcc = cv2.VideoWriter fourcc(*'XVID')
out1 = cv2.VideoWriter('./data/record0.mp4',fourcc, 20.0, frame_size) #save a grey video
out2 = cv2.VideoWriter('./data/record1.mp4',fourcc, 20.0, frame_size,isColor=False) # save clr vdo
while True:
  retval, frame = cap.read()
  if not retval:
    break
  gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
```

04. matplot 비디오 디스플레이

```
15
                                           retval, frame = cap.read() # 첫 프레임 캡처
# 0211.py
                                           im = plt.imshow(cv2.cvtColor(frame, cv2.COLOR_BGR2RGB))
import cv2
import matplotlib.pyplot as plt
                                           #3
#1
                                           while True:
def handle_key_press(event):
                                             retval, frame = cap.read() # 프레임 캡처
  if event.key == 'escape':
                                             if not retval:
    cap.release()
                                                break
    plt.close()
                                               plt.imshow(cv2.cvtColor(frame, cv2.COLOR_BGR2RGB))
def handle_close(evt):
                                             im.set_array(cv2.cvtColor(frame, cv2.COLOR_BGR2RGB))
  print('Close figure!')
                                             fig.canvas.draw()
  cap.release()
                                           # fig.canvas.draw_idle()
#2 프로그램 시작
                                             fig.canvas.flush_events() # plt.pause(0.001)
cap = cv2.VideoCapture(0) # 0번 카메라
                                           if cap.isOpened():
plt.ion() # 대화모드 설정
                                             cap.release()
fig = plt.figure(figsize=(10, 6)) # fig.set_size_inches(10, 6)
plt.axis('off')
#ax = fig.gca()
#ax.set axis off()
fig.canvas.set_window_title('Video Capture')
fig.canvas.mpl_connect('key_press_event', handle_key_press)
fig.canvas.mpl connect('close event', handle close)
```

04. matplot 비디오 디스플레이

```
# 0212.py
import cv2
import matplotlib.pyplot as plt
import matplotlib.animation as animation
# 프로그램 시작
cap = cv2.VideoCapture(0)
fig = plt.figure(figsize=(10, 6)) # fig.set_size_inches(10, 6)
fig.canvas.set_window_title('Video Capture')
plt.axis('off')
def init():
  global im
  retval, frame = cap.read() # 첫 프레임 캡처
  im = plt.imshow(cv2.cvtColor(frame, cv2.COLOR_BGR2RGB))
def updateFrame(k):
  retval, frame = cap.read()
  if retval:
    im.set_array(cv2.cvtColor(frame, cv2.COLOR_BGR2RGB))
ani = animation.FuncAnimation(fig. updateFrame, init_func=init, interval=50)
plt.show()
if cap.isOpened():
  cap.release()
```

```
# 0213.py
class Video:
  def __init__(self, device=0):
    self.cap = cv2.VideoCapture(device)
    self.retval, self.frame = self.cap.read()
    self.im = plt.imshow(cv2.cvtColor(self.frame, cv2.COLOR_BGR2RGB))
    print('start capture ...')
  def updateFrame(self, k):
    self.retval, self.frame = self.cap.read()
    self.im.set_array(cv2.cvtColor(camera.frame, cv2.COLOR_BGR2RGB))
  def close(self):
    if self.cap.isOpened():
       self.cap.release()
    print('finish capture.') # 프로그램 시작
fig = plt.figure()
fig.canvas.set_window_title('Video Capture')
plt.axis("off")
camera = Video()
##camera = Video('./data/vtest.avi')
ani = animation.FuncAnimation(fig, camera.updateFrame, interval=50)
plt.show()
camera.close()
```

```
# 0214.py
                                                                                               18
class Video(animation.FuncAnimation):
  def __init__(self, device=0, fig=None, frames=None,
             interval=50, repeat_delay=5, blit=False, **kwargs):
                                                                   def close(self):
    if fig is None:
                                                                       if self.cap.isOpened():
       self.fig = plt.figure()
                                                                          self.cap.release()
       self.fig.canvas.set_window_title('Video Capture')
                                                                       print("finish capture.")
       plt.axis("off")
    super(Video, self).__init__(self.fig, self.updateFrame, init_func=self.init,
                     frames=frames, interval=interval, blit=blit,
                                                                   # 프로그램 시작
                     repeat_delay=repeat_delay, **kwargs)
                                                                   camera = Video()
                                                                   ##camera = Video('./data/vtest.avi')
    self.cap = cv2.VideoCapture(device)
    print("start capture ...")
                                                                   plt.show()
  def init(self):
                                                                   camera.close()
    retval, self.frame = self.cap.read()
    if retval:
       self.im = plt.imshow(cv2.cvtColor(self.frame, cv2.COLOR_BGR2RGB))
  def updateFrame(self, k):
    retval, self.frame = self.cap.read()
    if retval:
       self.im.set_array(cv2.cvtColor(camera.frame, cv2.COLOR_BGR2RGB))
     return self.im.
```

```
# 0215.py
import cv2
import numpy as np
import matplotlib.pyplot as plt
import matplotlib.animation as animation
class Video(animation.FuncAnimation):
  def __init__(self, device=0, fig=None, frames=None,
             interval=80, repeat delay=5, blit=False, **kwargs):
    if fig is None:
       self.fig, self.ax = plt.subplots(1, 2, figsize=(10,5))
       self.fig.canvas.set_window_title('Video Capture')
       self.ax[0].set_position([0, 0, 0.5, 1])
       self.ax[0].axis('off')
       self.ax[1].set_position([0.5, 0, 0.5, 1])
       self.ax[1].axis('off')
          plt.subplots_adjust(left=0,bottom=0,right=1,top=1,
##
                      wspace=0.05,hspace=0.05)
##
    super(Video, self).__init__(self.fig, self.updateFrame, init_func=self.init,
                     frames=frames, interval=interval, blit=blit,
                     repeat_delay=repeat_delay, **kwargs)
    self.cap = cv2.VideoCapture(device)
    print('start capture ...')
```

```
20
```

```
# 0215.py
  def init(self):
    retval, self.frame = self.cap.read()
    if retval:
      self.im0 = self.ax[0].imshow(cv2.cvtColor(self.frame, cv2.COLOR_BGR2RGB),
                      aspect = 'auto')
      self.im1 = self.ax[1].imshow(np.zeros(self.frame.shape, self.frame.dtype)
                      aspect = 'auto')
  def updateFrame(self, k):
    retval, self.frame = self.cap.read()
    if retval:
      self.im0.set_array(cv2.cvtColor(self.frame, cv2.COLOR_BGR2RGB))
       gray = cv2.cvtColor(self.frame, cv2.COLOR_BGR2GRAY)
      self.im1.set_array(cv2.merge((gray,gray,gray)))
  def close(self):
    if self.cap.isOpened():
      self.cap.release()
    print('finish capture.')
# 프로그램 시작
camera = Video()
plt.show()
camera.close()
```

04. matplot 비디오 디스플레이

